


Aries Flex

Quick-Start Guide



Front Button

Hold button for ½ second to initiate color LEDs (avoids causing false alarms). Sequences are for demo only – NLT will program to specific user requirements.